

1/6

FIG.1




FIG.3




FIG.4

HOST ENTRY	INTERFACE ID	IPV6 ADDRESS OF TRANSFER DESTINATION ROUTER
DEFAULT ENTRY	DEFAULT	IPV6 ADDRESS OF TRANSFER DESTINATION ROUTER

FIG.5




FIG.7A

DST INTERFACE ID	NEXT HOP
DEFAULT	→ TO BACKBONE
ff04:320:273:9730	→ IF3
ff01:233:431:4345	→ IF3
ff05:193:621:5484	→ IF4
...	

FIG.7B

DST INTERFACE ID	NEXT HOP
DEFAULT	→ IF1
ff04:320:273:9730	→ IF10
ff01:233:431:4345	→ IF9
...	

FIG.7C

DST INTERFACE ID	NEXT HOP
DEFAULT	→ IF6
ff04:320:273:9730	→ ON-LINK
...	